

# **BHM**

**Version 1.0.0**

# **Beray Hydrology Model**

## **User Guide**

**JUNE, 2013**

Beray Engineering, Construction and Information Technologies

[www.beraymuhendislik.com](http://www.beraymuhendislik.com)



## Content

Introduction .....	3
BHM (Beray Hydrology Model) Software .....	4
System requirements.....	4
Installation .....	4
Software.....	5
Generating a new project.....	5
Opening a project.....	11
Saving a project.....	12
Closing the project .....	12
Updating basin attributes .....	13
Adding-removing an elevation zone / Updating lake parameters.....	14
Updating Monitored Rain Temperature Flow Data .....	15
Updating Average Monthly Evaporation and Temperature Values.....	16
Calculation of flow estimation.....	17
Calibration of basin parameters .....	20
Closing the project .....	21
HBV Hydrology Model .....	22
Snow Module .....	22
Soil Module.....	24
Response Function .....	25
Routing Routine .....	26
Error calculation .....	27
RMSE.....	27
Pearson product-moment correlation coefficient .....	27
Nash-Sutcliffe model yield coefficient.....	28



## Introduction

HBV hydraulic model was designed by Sten Bergström in 1972. It was improved by SMHI (Swedish Meteorology and Hydrology Institute) in order to be used inside Sweden in 1976. Therefore, HBV and its different versions were used in approximately 30 countries up until today.

This is a conceptual model, which is easy to understand, learn and apply. It has proved good results in several basins that it was applied. It has been used as a standard model for the flow estimation lessons especially in northern countries.



## **BHM (Beray Hydrology Model) Software**

BHM software is HBV based flow estimation software developed by Beray Engineering, Construction and Information Technologies.

### **System requirements**

Windows XP, Windows Vista, Windows 7, Windows 8 operating systems.

Microsoft .Net 4.0 or upper versions.

### **Installation**


Installation file is "setup.exe" file. In order to install the software, this file is clicked and installation is completed by following the instructions in the installation window.



## Software

BHM software calculates flow, using meteorological estimation, precipitation and temperature data in a certain basin by means of the parameters that were applied by algorithm processing monitored rain, temperature and flow values.


In "C:\\" disc, "BHM" file is generated, when the program is started to run. While the new generated project is saved, it is saved under this directory unless a different file is not selected by the user.



Snapshot 1.1 – BHM Main Screen

## Generating a new project

New project generation screen is opened by "New" menu entry under "File" menu or by the "New project" icon inside the toolbar.



Snapshot 2.1 – BHM New Project Generation Menu Entry



Snapshot 2.2 – BHM New Project Generation Toolbar Icon

Project parameters are opened with initial values in "Generate New Project" screen. This screen consists of four tabs.

"Basin Parameters"

"Elevation – Vegetation regions"



“Average Monthly Evaporation and Temperature Values”  
“Monitored Rain, Temperature and Flow Values”

Yeni Proje Oluştur

Havza Parametreleri | Yükseklik - Bitkisel Bölgeler | Aylık Ortalama Buharlaştırma ve Sıcaklık Değerleri | Gözlenen Yağış Sıcaklık Akım Değerleri

Proje Özellikleri

Proje İsmi

Yeni\_Proje

Havza Parametreleri

Alan [km²]	Pcalc [mm]	Tcalt [C°]	Cet	PERC	UZL	Maxbas	K0	K1	K2
0	10	0.6	0.18	1.65	24.85	3	0.45	0.14	0.04

Havza Başlangıç Değerleri

SnowPack [mm]	SUZ [mm]	SLZ [mm]	SoilMoisture [mm]
0	0	0	0

\*Başlangıç değerleri bilinmiyorsa "0" olarak bırakılmalıdır.

İleri

Snapshot 2.3 – BHM New Project Generation Screen Basin Parameters Tab

The name of the project is entered into “Project Name” field.

“Basin Parameters” group;

“Area” value is the total area of the basin [km²]

“Pcalc” value is the precipitation change in the basin in every 1000 meters [mm]

“Tcalt” value is the temperature change in the basin in every 100 meters

“Cet” value is the characteristic parameter of the basin

“PERC” value is the characteristic parameter of the basin

“UZL” value is the characteristic parameter of the basin

“Maxbas” value is the characteristic parameter of the basin

“K0” value is the characteristic parameter of the basin

“K1” value is the characteristic parameter of the basin

“K2” value is the characteristic parameter of the basin

If no other values except “Area” value in this group are known, the initial values of the program must remain. A new project cannot be generated unless an “Area” value higher than zero is entered.

“Basin Initial Values” group shows initial values;

“SnowPack” value is the initial snow amount value of the basin [mm]

“SUZ” value is the water amount in the initial upper groundwater zone of the basin [mm]

“SLZ” value is the water amount in the initial lower groundwater zone of the basin [mm]

“SoilMoisture” value is the initial soil moisture amount of the basin [mm]

If the values in this group are unknown, they must remain “0”. Initial values are automatically calculated while the program makes the calculation.



The "Forward" button at right bottom part of the screen leads to the next step in generating a new project.

**Yeni Proje Oluştur**

Havza Parametreleri | **Yükseklik - Bitkisel Bölgeler** | Aylık Ortalama Buharlaştırma ve Sıcaklık Değerleri | Gözlenen Yağış Sıcaklık Akım Değerleri

**Yükseklik Bölgesi Parametreleri**

No	Yükseklik [m]
1	0

**Bitkisel Bölge Parametreleri**

No	TT [C°]	BETA	FC	LP	SFCF	CFMAX	CFR	CFSlope	CWH
1	-0.39	1.18	245	0.33	1	2.6	0.05	0	0.1

**Göl Parametreleri**

Alan	Yükseklik [m]	TT [C°]	SFCF
0	0	0	1

**Yükseklik-Bitkisel Bölge Kesişim Alanları**

No	Doğu-Batı Alanı	Güney Alanı	Kuzey Alanı
1-1	1	0	0

Geri İleri

Snapshot 2.4 – BHM New Project Generation Screen Elevation – Vegetation Regions Tab

Different elevation regions and vegetation regions of the basin are described in "Elevation – Vegetation Regions" tab. Elevation regions or vegetation regions might be added or deleted with the use of "+" and "-" buttons. Basin must contain at least 1 elevation region or 1 vegetation region. The amount of "Elevation – Vegetation Regions Intersection Areas" is same with the multiplication of elevation regions and vegetation regions. There are 3 areas in this group. The value sum of these 3 areas has to be 1. The value must be given with the assumption that total area of the basin is 1. If more than 1 region exists, not only one intersection point, but the sum of all intersection point areas must be 1. If there is a lake in the basin, lake and total area of its intersection points have to be 1.

"Elevation Region Parameters" group;

"Elevation" area is the altitude of the region [m]

"Vegetation Region Parameters" group;

"TT" value is the freezing temperature of the vegetation region [C °]

"BETA" value is the characteristic parameter of the basin

"FC" value is the characteristic parameter of the basin

"LP" value is the characteristic parameter of the basin

"SFCF" value is the characteristic parameter of the basin

"CFMAX" value is the characteristic parameter of the basin

"CFR" value is the characteristic parameter of the basin

"CFSlope" value is the characteristic parameter of the basin

"CWH" value is the characteristic parameter of the basin

If the values in this group are unknown, initial values of the program must remain.



"Elevation – Vegetation Region Intersection Areas" group;

"No" value represents the intersection area belongs to elevation region and vegetation region number, respectively.

"East - West Area" value is the area that is aspect to east and west directions of the intersection area. Must have a value between 0 and 1.

"South Area" value is the area that is aspect to south direction of the intersection area. Must have a value between 0 and 1.

"North Area" value is the area that is aspect to north direction of the intersection area. Must have a value between 0 and 1.

"Lake Parameters" group;

"Area" is the value of the lake area inside the region. The value must be entered assuming total basin value is 1.

"Elevation" value is the altitude of the lake. If the lake is at the flow accumulation center of the basin, altitude is presumed as 0. Altitude must be given by assuming the bottom point of the basin is 0.

"TT" value is the freezing temperature of the lake water [C°].

"SFCF" is the characteristic value of the lake.

"Undo" button at the left bottom of the screen leads to the previous stage for generating a new project.

"Forward" button at the right bottom of the screen leads to the next stage for generating a new project.

Yeni Proje Oluştur

Havza Parametreleri | Yükseklik - Bitkisel Bölgeler | **Aylik Ortalama Buharlaşma ve Sıcaklık Değerleri** | Gözlenen Yağış Sıcaklık Akım Değerleri

Dosyadan Yükle

Aylik Ortalama Buharlaşma Değerleri

Ay	Buharlaşma Ortalaması [mm]
1	0
2	0
3	0
4	0
5	0
6	0
7	0
8	0
9	0
10	0
11	0
12	0

Dosyadan Yükle

Aylik Ortalama Sıcaklık Değerleri

Ay	Sıcaklık Ortalaması [C°]
1	0
2	0
3	0
4	0
5	0
6	0
7	0
8	0
9	0
10	0
11	0
12	0

Geri

İleri

Snapshot 2.5 – BHM New Project Generation Screen Monthly Average Evaporation and Temperature Values Tab



## BHM Test Basin Monthly Evaporation Data

0.05  
0.14  
0.46  
1.5  
3.01  
4.15  
3.66  
2.72  
1.42  
0.43  
0.03  
0

"Average Evaporation" values [mm] and "Average Temperature" values [C°] must be entered in "Monthly Average Evaporation and Temperature Values" tab. "Month" values represents the month numbers in a year (1=January, 2=February, 3=March, 4=April, 5=May, 6=June, 7=July, 8=August, 9=September, 10=October, 11=November, 12=December). Monthly values entered, represent all the days in that month.

"Load from the file" button is used to load the values from ".txt" file. First line of the text files must be the definition line and program does not take them into account. 12 values are read one under the other, starting from the second line.

Accurate calculation and load of these parameters significantly affects the success of the flow estimation.

"Undo" button at the left bottom of the screen leads to the previous stage for generating a new project.

"Forward" button at the right bottom of the screen leads to the next stage for generating a new project.

Gün (gün-ay-yıl)	Yağış [mm]	Sıcaklık [C°]	Akım [m³/sn]
01.01.1981	0.00	-1.00	0.01
02.01.1981	0.00	-3.60	0.02
03.01.1981	0.20	-8.00	0.02
04.01.1981	0.10	-10.30	0.02
05.01.1981	0.00	-15.00	0.02
06.01.1981	0.00	-17.60	0.02
07.01.1981	0.00	-12.80	0.02
08.01.1981	1.20	-4.70	0.02
09.01.1981	1.70	3.00	0.08
10.01.1981	0.00	-3.40	0.19
11.01.1981	0.00	-5.10	0.16
12.01.1981	1.10	1.30	0.16
13.01.1981	0.00	-4.80	0.19
14.01.1981	11.30	-5.10	0.19

Snapshot 2.6 – BHM New Project Generation Screen Monitored Precipitation Temperature Flow Values Tab



Monitored precipitation, temperature and flow values of the basin are read from ".txt" formatted file in "Monitored Precipitation Flow Temperature Values" tab via "Load Precipitation Temperature Flow Values" button. First line of the text file must be the definition line and program does not take them into account. Program respectively reads "day", "precipitation", "temperature" and "flow" values. There must be only one day's information in every line. Otherwise, program will give reading error.



Sample file must be as below:

Day	Precipitation	Temp.	Flow
19810101	0	-1	0.002
19810102	0	-3.6	0.005
19810103	0.2	-8	0.005
19810104	0.1	-10.3	0.005
19810105	0	-15	0.005
19810106	0	-17.6	0.004
19810107	0	-12.8	0.004
19810108	1.2	-4.7	0.004
19810109	1.7	3	0.018
19810110	0	-3.4	0.04


Day format must be as "yyyyMMdd" (19810101), "dd.MM.yyyy" (01.01.01981) or "d.M.yyyy" (1.1.1981). All the days in the file must be written in the same format. 'y' letter represent year information, 'M' letter represents month information and 'd' letter represents day information.

"Undo" button at the left bottom of the screen leads to the previous new project generation step. "Save" button at the right bottom of the screen generates a new project. This button brings the project selection screen for the user in order to save the project, if clicked. Described project is saved to the designated directory after the selection of the folder. Project file has a ".bhm" extension. A file named "Project Files" is generated at the same directory with this file. 'sqlite' database file is present in this file. Changes to these files must not be made in order to ensure a proper functioning of the project.

After the successful save of the project, it can be opened automatically with the BHM program. This process might vary couple of minutes according to the observed data mass and computer processing speed.


## Opening a project

Requested project load file carrying a ".bhm" extension is selected via "Open" sub-menu item of "File" menu or project selection screen that is opened by "Open Project" icon and project is loaded to the program. This process might vary couple of minutes or more according to the observed data mass and computer processing speed.



Snapshot 3.1 – BHM Open Project menu item





*Screenshot 3.2 – BHM "Open Project" toolbar icon*

## Saving a project

Changes made to the project are saved via "Save" sub-menu item of "File" menu or "Save Project" icon in the toolbar. Save operation is irreversible. The changes to the project cannot be saved to project file if the program is shut down without saving the project. Save process might take a couple of minutes or more if there are several changes to the observed data.



*Snapshot 4.1 – BHM Project save menu item*



*Snapshot 4.2 – BHM Project save toolbar icon*

## Closing the project

"Close the Project" sub-menu item in "File" menu is used to shut down the loaded project in BHM program.





Screenshot 5.1 – BHM Project shut down menu item

## Updating basin attributes

"Basin Data" sub-menu item and "Basin Menu" screen is opened from "Project" menu.



Snapshot 6.1 – BHM Basin data menu item

**Havza Parametreleri**

Alan [km <sup>2</sup> ]	Pcalt [mm]	Tcalt [C°]	Cet	PERC	UZL	Maxbas	K0	K1	K2
400.00	10.00	0.60	0.18	1.65	24.85	3.00	0.45	0.14	0.04

**Havza Başlangıç Değerleri**

SnowPack [mm]	SUZ [mm]	SLZ [mm]	SoilMoisture [mm]
0.00	0.00	0.00	0.00

\*Başlangıç değerleri bilinmiyorsa "0" olarak bırakılmalıdır.

Kapat

Snapshot 6.2 – BHM Basin data update screen

Intended data changes are made in the screen and screen is closed.



The changes here are kept in the memory after the screen is closed. Updated data are used if a calculation is intended. Project must be saved in order to save the changed data

Please see "Generate a New Project" section for detailed information on parameters.

## Adding-removing an elevation zone / Updating lake parameters

"Elevation –Vegetation – Lake Region Parameters" screen is opened via "Elevation –Vegetation – Lake Region Parameters" sub menu item in project menu.



Snapshot 7.1 – BHM Elevation –Vegetation – Lake Region Parameters menu item

The screenshot displays the 'Yükseklik Bölgeleri - Bitkisel Bölgeler - Göl Bölgesi' screen. It contains four main sections with tables for parameter management:

- Yükseklik Bölgesi Parametreleri:** A table with columns 'No' and 'Yükseklik [m]'. It contains one row with '1.00' and '0.00'.
- Bitkisel Bölge Parametreleri:** A table with columns 'No', 'TT [C°]', 'BETA', 'FC', 'LP', 'SFCF', 'CFMAX', 'CFR', 'CFSlope', and 'CWH'. It contains one row with values: '1.00', '-0.39', '1.18', '245.00', '0.33', '1.00', '2.60', '0.05', '0.00', and '0.10'.
- Göl Parametreleri:** A table with columns 'Alan', 'Yükseklik [m]', 'TT [C°]', and 'SFCF'. It contains one row with values: '0.00', '0.00', '0.00', and '1.00'.
- Yükseklik-Bitkisel Bölge Kesişim Alanları:** A table with columns 'No', 'Doğu-Batı Alanı', 'Güney Alanı', and 'Kuzey Alanı'. It contains one row with values: '1-1', '1.00', '0.00', and '0.00'.

At the bottom right, there is a 'Kapat' button.

Snapshot 7.2 – BHM Elevation –Vegetation – Lake Region Parameters Update Screen

Intended data changes are made in the screen and screen is closed. Elevation regions or vegetation regions might be added or deleted with the use of "+" and "-" buttons. Basin must contain at least 1 elevation region or 1 vegetation region. The amount of "Elevation – Vegetation Regions Intersection Areas" is same with the multiplication of elevation regions and vegetation



regions. There are 3 areas in this group. The value sum of these 3 areas has to be 1. The value must be given with the assumption that total area of the basin is 1. If more than 1 region exists, not only one intersection point, but the sum of all intersection point areas must be 1. If there is a lake in the basin, lake and total area of its intersection points have to be 1.

The changes here are kept in the memory after the screen is closed. Updated data are used if a calculation is intended. Project must be saved in order to save the changed data

Please see "Generate a New Project" section for detailed information on parameters.

## Updating Monitored Rain Temperature Flow Data

"Monitored Rain Temperature Flow Data" screen is opened via 'Monitored Rain Temperature Flow Data' sub-menu item in the "Project" menu.



Snapshot 8.1 – BHM Monitored Rain Temperature Flow Data Update menu item

The screenshot shows the 'Yağmur - Sıcaklık - Akım Verileri' screen. It contains a table with four columns: 'Gün (gün-ay-yıl)', 'Yağış [mm]', 'Sıcaklık [C°]', and 'Akım [m³/sn]'. The table displays data for the first 10 days of January 1981. The first row is highlighted in blue.

Gün (gün-ay-yıl)	Yağış [mm]	Sıcaklık [C°]	Akım [m³/sn]
01.01.1981	0.00	-1.00	0.01
02.01.1981	0.00	-3.60	0.02
03.01.1981	0.20	-8.00	0.02
04.01.1981	0.10	-10.30	0.02
05.01.1981	0.00	-15.00	0.02
06.01.1981	0.00	-17.60	0.02
07.01.1981	0.00	-12.80	0.02
08.01.1981	1.20	-4.70	0.02
09.01.1981	1.70	3.00	0.08
10.01.1981	0.00	-3.40	0.19

At the bottom right of the table, there is a red circular icon with a white exclamation mark and a button labeled 'Kapat'.

Snapshot 8.2 – BHM Monitored Rain Temperature Flow Data Update screen



Intended data changes are made in the screen and screen is closed. The changes here are kept in the memory after the screen is closed. Updated data are used if a calculation is intended. Project must be saved in order to save the changed data


Please see "Generate a New Project" section for detailed information on parameters.

## Updating Average Monthly Evaporation and Temperature Values

"Average Monthly Evaporation and Temperature Values" screen is opened via 'Average Monthly Evaporation and Temperature Values' sub-menu item in the "Project" menu.



Snapshot 9.1 – BHM Average Monthly Evaporation and Temperature Values Update menu item



Snapshot 9.2 – BHM Average Monthly Evaporation and Temperature Values Update screen

Intended data changes are made in the screen and screen is closed. The changes here are kept in the memory after the screen is closed. Updated data are used if a calculation is intended. Project must be saved in order to save the changed data




Please see "Generate a New Project" section for detailed information on parameters.

## Calculation of flow estimation

"Calculate flow value" screen is opened via 'Start' sub-menu item in the "Calculate" menu item or "Start (Calculate flow)" icon in the toolbar.



Snapshot 10.1 – BHM Flow Calculation Menu item



Snapshot 10.2 – BHM Flow Calculation Toolbar icon



Snapshot 10.3 – BHM "Calculate flow values" screen

Estimated flow of the basin is calculated with clicking "Calculate" button after selecting beginning and ending dates.


"Table", "Graphic" and "Error Rates" buttons appears in the screen after the flow is calculated. "Table" button is the display of the results on the table. This screen consists of two tabs;

"Flow Results"

"Detailed Results"



'Date', 'Observed Flow' and 'Simulated Flow' values are displayed in table format in the "Flow Results" tab. Other calculated parameters calculated in "Detailed Results" tab are added to the screen in table format. Table in the screen is saved to the described directory by the user in ".xls" (excel) format with "save" button.



Tarih	Gözlenen	Simüle Edilen
01.01.1981	0.01	0.06
02.01.1981	0.02	0.06
03.01.1981	0.02	0.06
04.01.1981	0.02	0.05
05.01.1981	0.02	0.05
06.01.1981	0.02	0.05
07.01.1981	0.02	0.05
08.01.1981	0.02	0.05
09.01.1981	0.08	0.21
10.01.1981	0.19	0.20
11.01.1981	0.16	0.19
12.01.1981	0.16	0.24
13.01.1981	0.19	0.23


Snapshot 10.4 – BHM Flow Results Table Screen

"Graphic" button displays the results in graphics. This screen consists of two tabs;  
"Monitored – Simulated Flow"

"Snow Cover"

"Save" button in this screen saves the graphic in the screen to the described directory by the user in ".jpg" format.





Snapshot 10.5 – BHM Flow Results Graphic Screen

"Error Rates" button calculates and displays Error rates between the observed flow and the simulated flow in the screen. Please see "Error Rates" section for detailed information on Error rates.

The screenshot shows a software window titled "Hata Oranları". It contains a table with the following data:

Başlangıç Günü	01.01.1981
Bitiş Günü	31.12.1991
Toplam gün	4017
Toplam gözlenen akım [m³]	1269131328
Toplam simüle edilen akım [m³]	1394188416
Ortalama Karekök Hatası	3.58
Korelasyon	0.57
Nash-Sutcliffe	-0.03


A "Kaydet" button is located in the bottom right corner.

Snapshot 10.6– BHM Flow Results Error Rates Screen




## Calibration of basin parameters


Basin calibration screen is opened via 'Calibrate – Monte Carlo Simulation' sub-menu item in "Calculate" menu or 'Monte Carlo Simulation' icon in toolbar.



Snapshot 11.1 – BHM Basin Calibration Menu Item



Snapshot 11.2 – BHM Basin Calibration Toolbar Icon



Snapshot 11.3 – BHM Monte Carlo Simulation Screen



Lower or upper limits in "Vegetation Region Parameters" and "Basin Parameters" groups are described. The program automatically prints the optimal values of these limits on the screen. Value ranges might be decreased if necessary. It is not suggested to increase the value range. Intended beginning and ending dates of calibration is selected in "Calibration Alternatives" group. "Simulation Number" value is the number that defines how many times the basin will be calibrated.

Calibration is started with "Start" button after defining Error parameters in "Error Filters" group. Please see "Error Parameters" section for more information on Error parameters.

Calibration results are in "Results" group. Calibrations that pass through error filters are displayed in "Results" section.

Sonuçlar	RMSE	Correlation	Nash Sutcliffe
Sonuç 1	0.29	0.90	0.73
Sonuç 2	0.32	0.82	0.66
Sonuç 3	0.54	0.54	0.05
Sonuç 4	0.39	0.77	0.51

Cet	K0	K1	K2	UZL	PERC
0.07	0.13	0.12	0.07	9.41	2.45
	TT	CFMAX	FC	LP	BETA
Bitkisel Bölge 1	-1.81	3.98	467.05	0.64	3.37

Hesaplandı. Başarılı simülasyon sayısı : 4


Snapshot 11.4 – BHM Calibration Results

Error values of the results are displayed at the left section. Parameter values generated by the result of calibration are displayed at the right side of the clicked result. "Save" button saves the values in ".xls" format to the user described directory.

"Load project" button changes the parameter values of the selected result with loaded project parameter values. This operation is irreversible. Data are saved to '.bhm' project file.

## Closing the project


"Exit" sub-menu item in "File" menu or "x" program item at right top of the program is used to close the program.



Snapshot 1 2.1 – BHM Program Closing Sub-menu item



## HBV Hydrology Model



It is basically formed of 4 modules:

	Input	Output
Snow Module	<ul style="list-style-type: none"> <li>↗ precipitation</li> <li>↗ temperature</li> </ul>	<ul style="list-style-type: none"> <li>↗ snow cover</li> <li>↗ snow melt</li> </ul>
Soil Module	<ul style="list-style-type: none"> <li>↗ potential evaporation</li> <li>↗ precipitation</li> <li>↗ snow melt</li> </ul>	<ul style="list-style-type: none"> <li>↗ act. evaporation</li> <li>↗ soil moisture</li> <li>↗ groundwater recharge</li> </ul>
Response function	<ul style="list-style-type: none"> <li>↗ groundwater recharge</li> </ul>	<ul style="list-style-type: none"> <li>↗ runoff</li> <li>↗ groundwater level</li> </ul>
Routing routine	<ul style="list-style-type: none"> <li>↗ runoff to creek</li> </ul>	<ul style="list-style-type: none"> <li>↗ calculated runoff</li> </ul>

### Snow Module

It is the module that snow covers and snow melts are calculated and processed after deciding whether the precipitation will fall to the basin surface as rain or snow. The form of the precipitation is decided according to freezing point threshold value of water (TT) that differentiates due to the elevation and pressure of the basin. If the temperature is lower than this value precipitation will be estimated as snow and if temperature is over this value precipitation will be estimated as rain, and it is processed.

T : Temperature [C°]



TT : Water freeze temperature [C°]

If,  $T > TT \rightarrow \text{rain}$

$T < TT \rightarrow \text{snow}$

If the precipitation is in snow form, the amount is multiplied by SFCF parameter and added to the snow cover on the surface.

P : Amount of precipitation

SP : Snow cover

SFCF : Snow Fall Correction Factor

$$SP = SP + (P * SFCF)$$

In the situation that air temperature is over the threshold value, day temperature equation is used to calculate snow melt of the snow cover. Generally having values between 1.5 and 1.4; CFMAX is the determining factor in calculating snow melt (Lower values in vegetation areas)

*CFMAX : Day factor coefficient [mm d<sup>-1</sup> C°<sup>-1</sup>]*

$$\text{melt} = CFMAX (T - TT)$$

Water content consists of melting snow and rain. There is certain water holding capacity of the snow at the surface. This capacity is calculated with the help of CWH parameter. This amount is subtracted from total water ingredient and liquid water is calculated.

*WC : Water content*

*Insoil : Liquid water ( Water that reaches to the soil)*

*CWH : Water holding parameter of the snow*

$$WC = \text{melt} + \text{rain}$$

$$\text{Insoil} = WC - (CWH * SP)$$

In situations that air temperature is lower than the threshold level and liquid water is formed, a certain amount of liquid water transforms into ice. CFR parameter is used for this calculation. Degrease amount of liquid water is calculated with this parameter according to another region's air temperature threshold level while water passes through this region.

CFR : Freezing parameter of liquid water

$$SP = SP + CFR * CFMAX * (TT - T)$$

$$WC = WC - CFR * CFMAX * (TT - T)$$



## Soil Module

An amount of the water that reaches to soil surface evaporates to the atmosphere. Evaporation occurs from soil surface, accumulated water surface and via plants. Plants deliver water from the earth in order to use it for photosynthesis. Majority of photosynthesis water is released back to the atmosphere as a result of transpiration of the leaves in photosynthesis process. Contextualizing of evaporation in earth and water accumulation and transpiration of plants is called as evapotranspiration. Calculation of evapotranspiration is one of the major components of the model. Therefore, the impact of the temperature on the flow is substantial while it is high in summer months.

A certain amount of water reaches to the earth surface evaporates, a certain amount of it generates the soil moisture and remaining amount feeds the underground water.

DQ : Groundwater  
SM : Soil moisture  
FC : Maximum capacity of the soil  
 $\beta$  : Figure parameter

$$DQ = Insoil(t) \left[ \frac{SM(t-1)}{FC} \right]^\beta$$

Every region has a different humidity capture capacity due to the earth structure and depth. Evaporation must be calculated beforehand to be able to calculate the humidity of the earth.

Tavg : Average temperature  
Epm : Average evaporation  
Ep : Potential evaporation  
Cet : Model parameter

$$Ep(t) = Epm(1 + Cet[T(t) - Tavg(t)])$$

When soil moisture is over FC\*LP, real evaporation occurs at the same speed with potential evaporation. When soil moisture is lower than FC\*LP, real evaporation is lower than potential evaporation.




Ea : Real evaporation

LP : soil permanent wilting point coefficient

If ;


$$SM < FC * LP \rightarrow Ea(t) = Ep(t) \left[ \frac{SM(t-1)}{(FC * LP)} \right]$$

$$SM \geq FC * LP \rightarrow Ea(t) = Ep(t)$$




Soil moisture is acquired by subtracting surface flow and real evaporation from the sum of initial humidity and liquid water.

$$SM(t) = SM(t-1) + P - DQ - Ea$$



## Response Function

This module estimates the flow at the exit of the basin relying on layer concept. The system consists of two conceptual layers that are over each other. First layer is used for the modeling of surface water and flows reaching lower layer and second layer is used for simulating base flow. These two layers are directly connected to each other by the usage of a constant drainage ratio (Qperc).



Surface flow forms the flows on the earth surface. Interflow represents the bottom side of the upper zone flows. Finally baseflow represents the flows at the lower zone. The bottom surface of the lower zone is an impermeable layer, which its top surface border is the water surface border of the lake inside the basin.



Q0 : Near surface flow

Q1 : Inter flow

Q2 : Base flow


Qperc : Percolation

SUZ : Storage in upper zone

SLZ : Storage in lower zone

UZL : Treshold parameter

Kperc : Descriptive parameter



$$SUZ > UZL \rightarrow Q0 = (SUZ - UZL) K0$$

$$SUZ(t) = SUZ(t-1) + DQ(t) - Q1 - Q2 - Qperc$$

$$SUZ \leq UZL \rightarrow Q0 = 0$$

$$SLZ(t) = SLZ(t-1) + Qperc - Q2$$

$$Q1 = SUZ K1$$

$$Qperc = SUZ Kperc$$


$$Q2 = SLZ K2$$

## Routing Routine

Time delays of subsurface flow in joining the flow is calculated with this module. Simulation flow is acquired by a triangular weight function, which its parameter is defined as MAXBAS, via summing up flow amounts.

$$Qsim = \sum_{(i)}^{MAXBAS} c(i) Qtotal(t-i+1)$$

$$c(i) = \int_{(i-1)}^{(i)} \left( \frac{2}{MAXBAS} \right) - \frac{MAXBAS}{2} \frac{4}{MAXBAS^2} du$$






## Error calculation

### RMSE

Average square root Error (RMSE) is a simple and effective formula used in calibration process. It is acquired by taking the square root of; square sum of the difference between daily observed and simulated amount, divided to total day numbers.



$Q_s$  : Simulated flow

$Q_o$  : Observed flow

$$RMSE = \sqrt{\frac{\sum_{i=1}^n (Q_s(t) - Q_o(t))^2}{n}}$$

Ideal RMSE = 0

### Pearson product-moment correlation coefficient

Pearson product-moment correlation coefficient ( $R_p$ ) is the coefficient that describes the direction and magnitude of relation between independent variables. This coefficient takes a value between (-1) and (+1). While positive values describe direct linear relationship, negative values describe opposite direction linear relationship. There is no linear relationship between the variables if the correlation coefficient is zero.

$\overline{Q_o}$  : Average observed flow

$\overline{Q_s}$  : Simulated average observed flow



$$R_p = \frac{\sum_{i=1}^n (Q_o - \overline{Q_o})(Q_s - \overline{Q_s})}{\sqrt{\sum_{i=1}^n (Q_o - \overline{Q_o})^2} \sqrt{\sum_{i=1}^n (Q_s - \overline{Q_s})^2}}$$

$$R_p = -1 \rightarrow \boxed{\text{Opposite direction linear relationship}}$$

$$R_p = 0 \rightarrow \boxed{\text{There is no linear relationship}}$$

$$R_p = 1 \rightarrow \boxed{\text{Direct linear relationship}}$$

### Nash-Sutcliffe model yield coefficient

Nash-Sutcliffe model yield coefficient ( $R_{NS}$ ) (Yield coefficient) is an effective formula for evaluation of estimation strength of the simulation.

$$R_{NS} = 1 - \frac{\sum_{t=1}^n (Q_s(t) - Q_o(t))^2}{\sum_{t=1}^n (Q_o(t) - \overline{Q_o})^2}$$

If :

$$R_{NS} = 1 \rightarrow \boxed{\text{Perfect coherency}}, Q_s = Q_o$$

$$R_{NS} = 0 \rightarrow \boxed{\text{Good or bad coherency according to the monitored precipitation amount}}$$

$$R_{NS} < 0 \rightarrow \boxed{\text{Very bad coherency}}$$